

A286 CRES Blind Rivets Installed Weight

Installed weight of A286 CRES NAS1919 & 1921 Blind rivets

Weight each in pounds

© 2020 Howmet Aerospace Inc.

PROTRUDING HEAD BLIND RIVETS				
GRIP LENGTH	NAS1919C			
	A286 CRES			
	1/8" (04) Dia	5/32" (05) Dia	3/16" (06) Dia	1/4" (08) Dia
00	.001080	.002204	---	---
01	.001294	.002361	.003833	---
02	.001533	.002731	.004355	.009233
03	.001772	.003101	.004877	.010168
04	.002011	.003471	.005399	.011105
05	.002250	.003841	.005921	.012043
06	.002489	.004211	.006443	.012980
07	---	.004581	.006965	.013916
08	---	.004951	.007487	.014855
09	---	.005321	.008009	.015791
10	---	.005691	.008531	.016729
11	---	---	.009053	.017665
12	---	---	.009575	.018601
13	---	---	---	.019540
14	---	---	---	.020476
15	---	---	---	---

FLUSH HEAD BLIND RIVETS				
GRIP LENGTH	NAS1921C A286 CRES			
	1/8" (04) Dia	5/32" (05) Dia	3/16" (06) Dia	1/4" (08) Dia
01	.000890	.001457	---	---
02	.001033	.001756	.002851	---
03	.001272	.002126	.003373	.007208
04	.001511	.002496	.003895	.008147
05	.001750	.002866	.004417	.009085
06	.001989	.003236	.004939	.010021
07	.002228	.003606	.005461	.010958
08	---	.003976	.005983	.011896
09	---	.004346	.006505	.012803
10	---	.004716	.007027	.013768
11	---	---	.007549	.014707
12	---	---	.008071	.015643
13	---	---	---	.016580
14	---	---	---	.017618
15	---	---	---	---