







FIGURE 5

FIGURE 6

INSTALLATION PROCEDURE

- 1. INSERT THE SCREW IN A PANEL HOLE PREPARED IN ACCORDANCE WITH CAL-STD-0273. SEE FIGURE 4.
- 2. PLACE THE RETAINING RING IN THE TOOL NOSE AS SHOWN IN FIGURE 3. NOTE THE RING ALIGNMENT PLACEMENT. SQUEEZE THE TOOL ONLY ENOUGH TO HOLD THE RING IN PLACE. DO NOT CRIMP.
- 3. ALIGN THE YELLOW LINES ON THE TOOL JAWS WITH THE SCREW SHANK SLOTS AND PLACE THE TOOL OVER THE SCREW THREADS AS SHOWN IN FIGURE 5 (THE RING WILL NOT ALLOW THE SCREW TO ENTER THE TOOL UNLESS THE INTERNAL RING TANGS ARE ALIGNED WITH THE SCREW SLOTS).
- 4. CRIMP THE RING INTO THE SCREW SLOTS UNTIL THE TOOL JAWS SHUT. IT IS NOT NECESSARY TO SQUEEZE TIGHTLY ONCE THE TOOL JAWS ARE SHUT. SEE FIGURE 6.
- 5. OPEN THE TOOL JAWS AND REMOVE THE TOOL FROM THE SCREW. CHECK FOR PROPER CRIMP BY PULLING ON THE RING WITH FINGERS. THE RING SHOULD NOT COME OFF THE SCREW. RE-CRIMP, IF NECESSARY.
- 6. CAUTION:
 KEEP THE TOOL JAWS AND NOSE AREA CLEAN AND UNDAMAGED. DEBRIS OR DAMAGE TO TOOL NOSE
 AREA OR JAWS MAY PREVENT PROPER RING CRIMPING.
- <7> INSTALLATION TOOL NUMBER CA2240T-() WAS CHANGED FROM FIGURE 1 TO LOOK LIKE THE PICTURE ON FIGURE 2. TOOLS ORDERED WILL BE SUPPLIED WITH THE PICTURE ON FIGURE 1 UNTIL PRESENT INVENTORIES ARE EXHAUSTED, AFTER WHICH ALL SHIPMENTS WILL HAVE THE TOOL ON FIGURE 2 ONLY.

USE INSTALLATION TOOL NUMBER	RETAINING RING PART NUMBER	SCREW THREAD SIZE REF
CA2240T-06	CA2240-06R	. 138-32UNC-3A
GA2240T-08	CA2240-08R	. 164-32INC-3A

 ŽL	APPROVED DATE	Fairchild AEROSPACE FASTENER DIV	ISION
CT /	5 DEC 91	ENGINEERING CENTER 3000 WEST LOMITA BOULEVARD	
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	REV. LETTER AND DATE	TORRANCE, CA 90505	
PRO	B 12 DEC 96	INSTALLATION, CRIMP-ON	
27	ECN NUMBER	RETAINING RINGS	
2427	AL ECN 39528	NETAINING AINGS	

CAGE CODE **29372**TRIDAIR PRODUCT

CA2240T-()

SHEET 2 OF 2

ECT NUMBER: 92-065, 95-019A AND 96-137